

MIXING CHAMBER PARTS FOR AMAL NEEDLE AND NON-NEEDLE (BINKS) TYPE CARBURETTERS

Component	Amal Carburetters NEEDLE TYPE				Binks or Non-Needle Type Carburetters				Price s. d.
	Type 4/ 74/ & 274/	Type 5/ 75/ & 275/	Type 6/ 76/ & 276/	Type 29/ 89/ & 289/	Type 46/	Type 47/	Type 48/	Type 49/	
Mixing Chamber	According to Engine	—	—	—	According to Engine	According to Engine	—	—	10 0
Ditto	—	According to Engine	—	—	According to Engine	—	According to Engine	—	12 0
Ditto	—	—	According to Engine	—	—	—	According to Engine	According to Engine	14 0
Ditto	—	—	—	According to Engine	—	—	—	—	16 0
Jet Block and Barrel complete, size 17 Bore	4/057	—	—	—	—	—	—	—	7 6
Ditto 21	4/058	—	—	—	—	—	—	—	7 6
Ditto 25	4/059	—	—	—	—	—	—	—	7 6
Ditto 28	—	5/057	—	—	—	—	—	—	7 6
Ditto 33	—	5/058	—	—	—	—	—	—	7 6
Ditto 39	—	—	6/057	—	—	—	—	—	7 6
Ditto 45	—	—	6/058	—	—	—	—	—	7 6
Ditto 51	—	—	6/059	—	—	—	—	—	7 6
Ditto 54	—	—	—	29/068	—	—	—	—	10 0
Ditto 58	—	—	—	29/069	—	—	—	—	10 0
Ditto 61	—	—	—	29/070	—	—	—	—	10 0
Ditto 65	—	—	—	29/071	—	—	—	—	10 0
Mixing Chamber Union Nut	4/062	4/062	6/062	—	—	47/033	4/062	6/062	2 3
Ditto	—	—	—	29/072	—	—	—	—	3 0
Mixing Chamber Cap	4/031	4/031	6/031	—	—	47/031	4/031	6/031	2 6
Ditto Ditto	—	—	—	29/041	—	—	—	—	3 0
Ditto Ditto	—	—	—	—	46/031	—	—	—	2 3
M/Chamber Cap Fixing Spring	4/235	4/235	6/235	29/201	—	—	—	—	9
Screw for ditto	4/241	4/241	6/241	4/241	—	—	—	—	2
Mixing Chamber Top	4/032	4/032	6/032	—	—	47/032	48/032	49/032	2 6
Ditto Ditto	—	—	—	29/042	—	—	—	—	3 3
Cable, per length complete	—	—	—	—	—	—	—	—	2 6
Midway Cable Adjusters	3792-3-4	3792-3-4	3792-3-4	3792-3-4	—	—	—	—	1 6
Cable Stop, top hat shape	6/132	6/132	6/132	—	—	6/132	6/132	6/132	3
Cable Adjuster	4/035	4/035	4/035	4/035	4/035	4/035	4/035	4/035	6
Cable Nipples	1482	1482	1482	1482	1482	1482	1482	1482	2
Throttle Valve Spring	4/037	4/037	4/037	29/047	4/037	4/046	4/046	6/046	4
Air Funnel	4/038	4/038	6/038	—	—	4/038	4/038	6/038	3 0
Ditto	—	—	—	29/048	—	—	—	—	3 6
Washer for Jet Block	4/040	4/040	6/040	29/050	—	47/040	4/040	6/040	2
Spring Clip for Needle	4/230	4/230	4/230	4/230	—	—	—	—	6
Holding Bolt	4/043	4/043	4/043	29/077	4/043	4/043	4/043	4/043	3 0
Air Valve	4/045	5/045	6/045	—	—	47/045	48/045	9/045	3 9
Ditto	—	—	—	29/055	—	—	—	—	4 0
Air Valve Spring	4/046	4/046	4/046	4/046	—	4/046	4/046	6/046	4
Air or Throttle Valve Guide	4/047	4/047	6/047	—	—	7/047	4/047	9/047	1 0
Ditto	—	—	—	29/057	—	—	—	—	1 3
Outlet Clip Screw	4/048	4/048	4/048	4/048	4/048	4/048	4/048	4/048	6
*Outlet Clip for 1" Outlet	4/049	4/049	4/049	—	—	4/049	4/049	—	2 6
* Ditto 1 1/8" ditto	—	5/050	5/050	—	—	5/050	5/050	—	2 6
* Ditto 1 1/4" ditto	—	—	—	27/058	—	—	—	—	3 0
* Ditto 1 1/2" ditto	—	—	6/051	6/051	—	—	6/051	—	2 6
* Ditto 1 3/4" ditto	—	—	—	27/059	—	—	—	—	3 0
* Ditto 1 7/8" ditto	—	—	—	—	46/040	—	—	—	2 0
* Ditto 2" ditto	—	—	—	—	46/041	—	—	—	2 0
Throttle Valve	4/052	5/052	6/052	—	—	47/054	48/054	49/054	6 0
Ditto	—	—	—	29/062	—	—	—	—	6 6
Ditto 35 bore	—	—	—	—	46/032	—	—	—	3 9
Ditto 41 bore	—	—	—	—	46/033	—	—	—	4 0
Throttle Valve 468 bore	—	—	—	—	46/034	—	—	—	4 6
Ditto 531 bore	—	—	—	—	46/035	—	—	—	4 6
Ditto 60 bore	—	—	—	—	46/036	—	—	—	4 6
Holding Bolt Washer	4/053	4/053	4/053	4/053	4/053	4/053	4/053	4/053	2 2
Needle Jet	4/061	4/061	4/061	29/076	—	—	—	—	2 6
Needle for Jet	4/065	5/065	6/065	29/075	—	—	—	—	2 0
Air Adjusting Screw	13/129	13/129	13/129	13/129	—	—	—	—	9
Spring for Ditto	4/148	4/148	4/148	4/148	—	—	—	—	3
Filter	—	—	—	—	7/073	49/063	49/063	49/063	9
Filter complete	—	—	—	—	7/099	7/099	7/099	7/099	2 3
Jet Key	—	—	—	—	—	—	—	—	1 6
Main Jet	4/042	4/042	4/042	4/042	—	—	—	—	8
Ditto	—	—	—	—	7/062	7/062	7/062	7/062	8
Pilot Jet	—	—	—	—	7/061	7/061	7/061	7/061	8
Throttle Stop Screw	4/063	4/063	4/063	4/063	—	47/059	49/059	49/059	9
Ditto ditto Lock Nut	16/010	16/010	16/010	16/010	—	49/060	49/060	49/060	2
Split Cotter Pin for Th'tle Valve	4/060	4/060	4/060	4/060	—	—	—	—	1
Strangler Thimble	—	—	—	—	46/037	—	—	—	1 6
Strangler Inner Sleeve	—	—	—	—	46/038	—	—	—	1 6
Strangler Lever	—	—	—	—	46/039	—	—	—	9
Valve Location Peg	—	—	—	—	49/066	—	—	—	4
Strangler Spring	—	—	—	—	46/042	—	—	—	4
Special Throttle Valve	—	—	—	—	—	47/055	—	—	6 0
Special Air Valve	—	—	—	—	—	47/056	—	—	3 0
Levis Throttle Valve	—	—	—	—	—	47/131	—	—	6 0
Jet Seat	—	—	—	—	—	47/034	48/034	49/034	1 6

Types 4/ 5/ 6/ and 29/ are Brass Mixing Chambers. Types 74/ 75/ 76/ and 89/ are Die-cast Mixing Chambers.

*Please State if Plain or Ridged Type.

Letter P stamped after Carburetter Type denotes Carburetter is Pump Type